

# Datta Enterprises

web : [www.dattadoor.com](http://www.dattadoor.com)

---

## Procedure of how to fit Glodoor Aqua (Bathroom Doors) :

- Four Sizes are available – **78” x 27”, 78” x 30”, 81” x 27” & 81” x 30” (Approximately) respectively & Thickness 28mm.**
- Carpenter can **adjust the size according to the Customers requirement** i.e. he can **easily cut** the door both vertically & horizontally with the help of **Cutting Machine or any other tool used for cutting Plywood.**
- Now Stick the **PVC Patti / Strips given along with the Door to the four sides with the help of SR 998 (Rubber Adhesive) which should be applied on both the sides simultaneously i.e. on Sides of the Doors as well as on Strips / Patti.** Lightly hammer on the four sides with the help of **Rubber / Tafflon hammer. Apply SR 998 (Rubber Adhesive) with the help of Paint Brush.**
- **Always use But-Hinges with zig-zag lining srew hole,** so that it will fit evenly on all the layer of Foam used as a filler.
- **Screw used should be Full Thread with 1.5” length.**
- While fixing the **Handle, Hanger Strip and Stopper use Full thread 1” length Screw**
- One should not use Conceal Locks but can use Cylindrical Locks.
- This door is only for Interior purpose & should not be directly expose to sun.
- Remember, wherever we had made use of the Screw, one should **pour around the Screw a thin lining of Stick Fast / Fevi Quick** for better grip and fitting.